



# SBV5220 VoIP Cable Modem


## Quick Installation Guide



1



2  
Insert the CD-ROM to make a USB connection or to read the User Guide.

  
Contact your VoIP provider before connecting your Motorola VoIP cable modem to your existing telephone wiring.  
  
Connect each TEL port to a telephone only, never to a traditional phone service.



7

5


To AC power

Ethernet  
**OR**

6

USB

Do not connect both the Ethernet and USB cable to your PC. Use one or the other. For Macintosh®, Linux®, or UNIX®, use Ethernet only.



Your computer may vary from illustration.



3

4



**MOTOROLA**

# SBV5220 VoIP Cable Modem

## Troubleshooting

**This information is to help you quickly solve a problem. Before calling your service provider, try unplugging and plugging in the cable modem power cord in the AC wall outlet to restart the cable modem.**

### The Problem

### The Solution

**Green POWER light is OFF**



Check that the SBV5220 is plugged into the wall outlet.



Try pressing the Standby button.

**Cannot receive or send data**



If you do not have cable-TV service, you will have to contact your service provider. If you have cable-TV service, then you can determine if the cable system is working properly by viewing a channel on your TV. If you cannot see a picture, then your data and voice service will not work and you need to call your cable-TV service provider.



Try pressing the Standby button if the Standby light is ON.



Check the coaxial cable on the SBV5220 and the wall outlet. Hand-tighten cable connectors if necessary.



Check that the USB or Ethernet cable is properly connected to the cable modem and your computer.



Check the IP address by following the steps in "Verifying the IP Address in Windows® 98SE, or Windows Me®" or "Verifying the IP Address in Windows® 2000 or Windows XP™" in the User Guide (on the CD-ROM). On computers using UNIX® or LINUX®, you must have Adobe® Acrobat® Reader® installed before opening the user guide. Call your cable provider if you need an IP address.



Check the lights on the front panel. Note the first light from top to bottom that is off. This light indicates where the error occurred, as described in "Front-Panel Lights an Error Conditions" in the User Guide (on the CD-ROM).



For solutions to telephone service problems, refer to "Troubleshooting" in the User Guide (on the CD-ROM).



MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. Windows, Windows Me, and Windows NT are registered trademarks and Windows XP is a trademark of Microsoft Corporation. Macintosh is a registered trademark of Apple Computer, Inc. Linux is a registered trademark of Linus Torvalds. Adobe and Acrobat Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the U.S. and/or other countries. UNIX is a registered trademark of the Open Group in the United States and other countries. All other product or service names are the property of their respective owners. No part of the contents of this document may be reproduced or transmitted in any form or by any means without the written permission of the publisher. © Motorola, Inc. 2006. All rights reserved.